

## 5. MAIN Electrical Parts List

Parts Code	Design LOC	Description
0202-002125	R4048,R4054,R4058	PB-SHORT
0404-001646	D7000	DIODE
0406-001561	ZD6006	DIODE
0406-001592	ZD6007	DIODE
0406-001808	D5002	DIODE
0406-001829	ZD1000	DIODE
0406-001860	ZD4001	DIODE
0406-001873	ZD6003,ZD6004	DIODE
0505-002088	Q5000,Q5002,Q7000	FET
0505-003234	Q6001,Q6002	FET
0601-003833	LED5000	LED
1001-002063	U2008	IC
1001-002065	U1003,U1013,U1027	IC
1001-002066	U1004	IC
1001-002078	U1002	IC
1001-002097	U7001	IC
1001-002099	U2003	IC
1001-002103	U1006,U1008	IC
1001-002108	U1011,U1040	IC
1001-002110	U1009,U1014,U1023	IC
1001-002110	U2002	IC
1009-001078	U3010	IC
1108-000675	UME5000	IC
1201-003869	U3012	IC
1201-004240	U6000	IC
1201-004310	PAM1000	IC
1201-004311	U1034,U1041,U2000	IC
1201-004314	U1030,U1032,U1037	IC
1201-004314	U1038	IC
1201-004315	PAM2000	IC
1201-004317	U1021	IC
1201-004318	U1044	IC
1202-001120	U6001	IC
1203-008475	U5004	IC
1203-008864	U7004	IC
1203-008865	U7005,U7011	IC
1203-008867	U2015,U7006,U7007	IC
1203-008872	U3006	IC

## 5. MAIN Electrical Parts List

1203-009157	U7012,U7013	IC
1203-009252	U7008	IC
1203-009462	U7003,U7010	IC
1203-009509	U2005,U2006,U2007	IC
1203-009511	U7002,U7009	IC
1203-009516	U5000	IC
1203-009517	U5001	IC
1203-009520	U5002	IC
1205-006274	U3005	IC
1205-006278	U3011	IC
1205-006402	U2010	IC
1205-006406	UCP4000	IC
1209-002513	U3007	IC
1209-002555	U3008	IC
1209-002627	U3003	IC
1404-001724	TH2000,TH4000,TH4001	THERMISTOR
1404-001724	TH4002,TH4003	THERMISTOR
2007-000172	R5020	R-CHIP
2007-003025	R6025,R6027	R-CHIP
2007-007197	R6020,R6021	R-CHIP
2007-007311	R5021	R-CHIP
2007-007741	R6005	R-CHIP
2007-008052	R4003,R4030,R4031	R-CHIP
2007-008052	R4032,R4038,R6036	R-CHIP
2007-008055	R1002,R1013,R2000	R-CHIP
2007-008055	R2005,R2010,R2011	R-CHIP
2007-008055	R5017	R-CHIP
2007-008210	R2001,R2002,R5046	R-CHIP
2007-008312	R4004	R-CHIP
2007-008419	R1006,R1007,R3007	R-CHIP
2007-008419	R4059,R5027,R5030	R-CHIP
2007-008419	R6003	R-CHIP
2007-008478	R5005	R-CHIP
2007-008483	R5016	R-CHIP
2007-008486	R5001	R-CHIP
2007-008516	R6024,R7006,R7008	R-CHIP
2007-008531	R6001,R6010,R7000	R-CHIP
2007-008531	R7001,R7002,R7004	R-CHIP
2007-008542	R6026,R6029	R-CHIP

---

## 5. MAIN Electrical Parts List

---

2007-008582	R2003,R2004,R2006	R-CHIP
2007-008582	R2007	R-CHIP
2007-008587	R1003,R3010	R-CHIP
2007-008588	R1005,R3006,R6023	R-CHIP
2007-008647	R1000,R1011,R4001	R-CHIP
2007-008647	R6030,R6031	R-CHIP
2007-009084	R5026	R-CHIP
2007-009155	R5028	R-CHIP
2007-009157	R2009,R4000,R4005	R-CHIP
2007-009157	R4006,R5002,R6028	R-CHIP
2007-009212	R6004	R-CHIP
2007-009314	R6002	R-CHIP
2007-009361	R1001,R1012,R6000	R-CHIP
2007-009361	R6022,R6032,R6033	R-CHIP
2007-009361	R6034	R-CHIP
2007-009408	R3000,R3001,R3002	R-CHIP
2007-009766	R1004	R-CHIP
2007-009804	R5013	R-CHIP
2007-009866	R5018	R-CHIP
2007-009920	R5004,R5007	R-CHIP
2007-009969	R6007	R-CHIP
2007-010691	R6011	R-CHIP
2007-010849	R4060	R-CHIP
2007-011043	R6018,R6019	R-CHIP
2007-011648	R1016,R1017,R1018	R-CHIP
2007-011648	R5000,R5006	R-CHIP
2007-012197	R5014	R-CHIP
2007-012202	R6009,R6014	R-CHIP
2203-000233	C3006,C3018	C-CERAMIC,CHIP
2203-000330	C3019	C-CERAMIC,CHIP
2203-000359	C3024	C-CERAMIC,CHIP
2203-002285	C6042	C-CERAMIC,CHIP
2203-005682	C1040,C1065,C1072	C-CERAMIC,CHIP
2203-005682	C2007,C3046,C5169	C-CERAMIC,CHIP
2203-005682	C5172,C6027,C7209	C-CERAMIC,CHIP
2203-005682	L1007,L1032,L1059	C-CERAMIC,CHIP
2203-005682	L1084,L1086	C-CERAMIC,CHIP
2203-005683	C6030,C6040	C-CERAMIC,CHIP
2203-005717	C1001,C1002	C-CERAMIC,CHIP

---

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

---

## 5. MAIN Electrical Parts List

---

2203-005725	C7000,C7005,C7006	C-CERAMIC,CHIP
2203-005725	C7014	C-CERAMIC,CHIP
2203-005726	C5051	C-CERAMIC,CHIP
2203-005729	C6023,C6026	C-CERAMIC,CHIP
2203-005731	C3061,C6033,C6034	C-CERAMIC,CHIP
2203-005732	C1036,C5150,C6022	C-CERAMIC,CHIP
2203-005732	C6025	C-CERAMIC,CHIP
2203-005734	C1053,L1064	C-CERAMIC,CHIP
2203-005736	C1009,C1010,C1013	C-CERAMIC,CHIP
2203-005736	C1027,C1030,C1032	C-CERAMIC,CHIP
2203-005736	C1033,C1034,C1037	C-CERAMIC,CHIP
2203-005736	C1045,C1046,C1050	C-CERAMIC,CHIP
2203-005736	C1063,C1069,C1078	C-CERAMIC,CHIP
2203-005736	C1094,C1097,C1099	C-CERAMIC,CHIP
2203-005736	C1119,C1130,C1131	C-CERAMIC,CHIP
2203-005736	C1132,C1158,C1165	C-CERAMIC,CHIP
2203-005736	C1166,C1179,C2003	C-CERAMIC,CHIP
2203-005736	C2013,C2077,C2078	C-CERAMIC,CHIP
2203-005736	C2127,C3020,C3021	C-CERAMIC,CHIP
2203-005736	C3023,C3026,C3027	C-CERAMIC,CHIP
2203-005736	C3029,C3030,C3037	C-CERAMIC,CHIP
2203-005736	C3044,C3054,C3055	C-CERAMIC,CHIP
2203-005736	L1022,L1028,L1034	C-CERAMIC,CHIP
2203-005736	L1075,L1085,L2005	C-CERAMIC,CHIP
2203-005736	L2021,L3011	C-CERAMIC,CHIP
2203-005777	C1038,C1049	C-CERAMIC,CHIP
2203-005789	C1003,C1023,C1025	C-CERAMIC,CHIP
2203-005789	C1058,C1062,C1106	C-CERAMIC,CHIP
2203-005789	C1109,C1120,C1122	C-CERAMIC,CHIP
2203-005789	C2006,C2008,C2025	C-CERAMIC,CHIP
2203-005789	C2074,L1008,L2026	C-CERAMIC,CHIP
2203-005792	C1175	C-CERAMIC,CHIP
2203-005806	C1020,C1060	C-CERAMIC,CHIP
2203-006048	C3051,C3057	C-CERAMIC,CHIP
2203-006121	C6015	C-CERAMIC,CHIP
2203-006194	C3041,C5070,C6014	C-CERAMIC,CHIP
2203-006305	C1111,C1112,L1102	C-CERAMIC,CHIP
2203-006379	C1164,C3045	C-CERAMIC,CHIP
2203-006400	C1005,C1007,C1028	C-CERAMIC,CHIP

## 5. MAIN Electrical Parts List

2203-006400	C1064,C1104,C1110	C-CERAMIC,CHIP
2203-006400	C1114,C1123,C1142	C-CERAMIC,CHIP
2203-006400	C1144,C1155,C1160	C-CERAMIC,CHIP
2203-006400	C2022,C2024,C2040	C-CERAMIC,CHIP
2203-006400	C3003,C3004,C3009	C-CERAMIC,CHIP
2203-006400	C4017,C6031,C6035	C-CERAMIC,CHIP
2203-006410	L1025	C-CERAMIC,CHIP
2203-006423	C1031,C1054,C1101	C-CERAMIC,CHIP
2203-006423	C1102,C1103,C1124	C-CERAMIC,CHIP
2203-006423	C1125,C1127,C1143	C-CERAMIC,CHIP
2203-006423	C1146,C2027,C2028	C-CERAMIC,CHIP
2203-006423	C2030,C2031,C2033	C-CERAMIC,CHIP
2203-006423	C2035,C2036,C2038	C-CERAMIC,CHIP
2203-006423	C2039,C2041,C2042	C-CERAMIC,CHIP
2203-006423	C2044,C2046,C2050	C-CERAMIC,CHIP
2203-006423	C2052,C2053,C2056	C-CERAMIC,CHIP
2203-006423	C2057,C2058,C2059	C-CERAMIC,CHIP
2203-006423	C2062,C2063,C2064	C-CERAMIC,CHIP
2203-006423	C2065,C2066,C2067	C-CERAMIC,CHIP
2203-006423	C2068,C2069,C2070	C-CERAMIC,CHIP
2203-006423	C2071,C2095,C2097	C-CERAMIC,CHIP
2203-006423	C2098,C3034,C3052	C-CERAMIC,CHIP
2203-006423	C3066,C4004,C4005	C-CERAMIC,CHIP
2203-006423	C4007,C4010,C4011	C-CERAMIC,CHIP
2203-006423	C4012,C4013,C4014	C-CERAMIC,CHIP
2203-006423	C4015,C4016,C4018	C-CERAMIC,CHIP
2203-006423	C4019,C4021,C4022	C-CERAMIC,CHIP
2203-006423	C4023,C4036,C4037	C-CERAMIC,CHIP
2203-006423	C4045,C4051,C4052	C-CERAMIC,CHIP
2203-006423	C4053,C4055,C4059	C-CERAMIC,CHIP
2203-006423	C4061,C4063,C4064	C-CERAMIC,CHIP
2203-006423	C4082,C5029,C5034	C-CERAMIC,CHIP
2203-006423	C5053,C5081,C5087	C-CERAMIC,CHIP
2203-006423	C5104,C5144,C6006	C-CERAMIC,CHIP
2203-006423	C6007,C6021,C6024	C-CERAMIC,CHIP
2203-006556	C1000,C1016,C1129	C-CERAMIC,CHIP
2203-006556	C5146	C-CERAMIC,CHIP
2203-006611	C1075,C1093,L1024	C-CERAMIC,CHIP
2203-006642	C6028,C6029,C6093	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

2203-006642	C6094	C-CERAMIC,CHIP
2203-006665	L2037	C-CERAMIC,CHIP
2203-006668	C2115,C2116,C2117	C-CERAMIC,CHIP
2203-006668	C6017	C-CERAMIC,CHIP
2203-006674	L2001	C-CERAMIC,CHIP
2203-006707	C6012,L1094	C-CERAMIC,CHIP
2203-006839	C1022,C1024,C1044	C-CERAMIC,CHIP
2203-006839	C1047,C1083,C1089	C-CERAMIC,CHIP
2203-006839	C1105,C1121,C2005	C-CERAMIC,CHIP
2203-006839	C2010,C2111,C3053	C-CERAMIC,CHIP
2203-006839	C7030,C7053	C-CERAMIC,CHIP
2203-006841	C6036	C-CERAMIC,CHIP
2203-006846	C1081	C-CERAMIC,CHIP
2203-006896	C2015	C-CERAMIC,CHIP
2203-006968	C1004,C1048,C1095	C-CERAMIC,CHIP
2203-006968	C1134,C1150,C1156	C-CERAMIC,CHIP
2203-006968	C1168,L1016,L1035	C-CERAMIC,CHIP
2203-006968	U1043	C-CERAMIC,CHIP
2203-006979	C7035	C-CERAMIC,CHIP
2203-006994	C1082	C-CERAMIC,CHIP
2203-007240	C5110,C5118,C5127	C-CERAMIC,CHIP
2203-007240	C5145	C-CERAMIC,CHIP
2203-007271	C7021	C-CERAMIC,CHIP
2203-007317	C2083,C2084,C2088	C-CERAMIC,CHIP
2203-007317	C3007,C3043,C4078	C-CERAMIC,CHIP
2203-007317	C5013,C5014,C5023	C-CERAMIC,CHIP
2203-007317	C5024,C5025,C5026	C-CERAMIC,CHIP
2203-007317	C5036,C5076,C5167	C-CERAMIC,CHIP
2203-007317	C5175,C6010,C6016	C-CERAMIC,CHIP
2203-007317	C7003,C7004,C7008	C-CERAMIC,CHIP
2203-007317	C7011,C7020	C-CERAMIC,CHIP
2203-007391	C1041,C1042,C2034	C-CERAMIC,CHIP
2203-007391	C4035	C-CERAMIC,CHIP
2203-007393	C1018,C1085,C2017	C-CERAMIC,CHIP
2203-007393	C2085,C2087,C2089	C-CERAMIC,CHIP
2203-007393	C2090,C2091,C2092	C-CERAMIC,CHIP
2203-007393	C2093,C2094,C2119	C-CERAMIC,CHIP
2203-007393	C2120,C2121,C3008	C-CERAMIC,CHIP
2203-007393	C5019,C5049,C5059	C-CERAMIC,CHIP

## 5. MAIN Electrical Parts List

2203-007393	C5080,C5182,C5183	C-CERAMIC,CHIP
2203-007393	C5186	C-CERAMIC,CHIP
2203-007425	C5105	C-CERAMIC,CHIP
2203-007456	C5171	C-CERAMIC,CHIP
2203-007796	C2037,C2096,C2106	C-CERAMIC,CHIP
2203-007796	C3010,C3011,C3013	C-CERAMIC,CHIP
2203-007796	C3042,C3050,C3056	C-CERAMIC,CHIP
2203-007796	C3060,C4000,C4001	C-CERAMIC,CHIP
2203-007796	C4002,C4003,C4006	C-CERAMIC,CHIP
2203-007796	C4008,C4009,C4020	C-CERAMIC,CHIP
2203-007796	C4031,C4032,C4033	C-CERAMIC,CHIP
2203-007796	C4034,C4038,C4039	C-CERAMIC,CHIP
2203-007796	C4040,C4041,C4042	C-CERAMIC,CHIP
2203-007796	C4043,C4044,C4048	C-CERAMIC,CHIP
2203-007796	C4049,C4050,C4054	C-CERAMIC,CHIP
2203-007796	C4056,C4058,C4060	C-CERAMIC,CHIP
2203-007796	C4065,C4074,C4079	C-CERAMIC,CHIP
2203-007796	C4080,C4081,C5003	C-CERAMIC,CHIP
2203-007796	C5004,C5007,C5009	C-CERAMIC,CHIP
2203-007796	C5017,C5035,C5047	C-CERAMIC,CHIP
2203-007796	C5048,C5052,C5054	C-CERAMIC,CHIP
2203-007796	C5056,C5057,C5058	C-CERAMIC,CHIP
2203-007796	C5060,C5065,C5066	C-CERAMIC,CHIP
2203-007796	C5067,C5068,C5074	C-CERAMIC,CHIP
2203-007796	C5075,C5077,C5078	C-CERAMIC,CHIP
2203-007796	C5083,C5092,C5093	C-CERAMIC,CHIP
2203-007796	C5094,C5095,C5100	C-CERAMIC,CHIP
2203-007796	C5141,C5142,C5143	C-CERAMIC,CHIP
2203-007796	C5152,C5153,C5154	C-CERAMIC,CHIP
2203-007796	C6001,C6020,C6039	C-CERAMIC,CHIP
2203-007796	C7001,C7002,C7009	C-CERAMIC,CHIP
2203-007796	C7012,C7013,C7019	C-CERAMIC,CHIP
2203-007796	C7023,C7024,C7025	C-CERAMIC,CHIP
2203-007796	C7026,C7027,C7033	C-CERAMIC,CHIP
2203-007796	C7034,C7046,C7047	C-CERAMIC,CHIP
2203-007796	C7048,C7049,C7055	C-CERAMIC,CHIP
2203-007796	C7056,C7058,C7063	C-CERAMIC,CHIP
2203-008097	C5124	C-CERAMIC,CHIP
2203-008242	C4066,C4067,C4083	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

2203-008242	C7022,C7029,C7045	C-CERAMIC,CHIP
2203-008242	C7052	C-CERAMIC,CHIP
2203-008243	C1019,C1080,C6032	C-CERAMIC,CHIP
2203-008312	C5022,C5028,C5140	C-CERAMIC,CHIP
2203-008394	C1068	C-CERAMIC,CHIP
2203-008654	C5170	C-CERAMIC,CHIP
2203-008749	C5111,C5113,C7038	C-CERAMIC,CHIP
2203-008749	C7039	C-CERAMIC,CHIP
2203-008860	C1039,C1066,C1073	C-CERAMIC,CHIP
2203-008860	C2012,C3002,C3059	C-CERAMIC,CHIP
2203-008860	C5030,C5084,C5086	C-CERAMIC,CHIP
2203-008860	C5090,C6002,C7028	C-CERAMIC,CHIP
2203-008860	C7031,C7032,C7037	C-CERAMIC,CHIP
2203-008860	C7051,C7054	C-CERAMIC,CHIP
2203-008876	C2014,C2086,C3058	C-CERAMIC,CHIP
2203-008876	C3063,C5010,C5018	C-CERAMIC,CHIP
2203-008876	C5031,C5037,C5042	C-CERAMIC,CHIP
2203-008876	C5046,C5055,C5061	C-CERAMIC,CHIP
2203-008876	C5062,C5063,C5064	C-CERAMIC,CHIP
2203-008876	C5072,C5082,C5088	C-CERAMIC,CHIP
2203-008876	C5089,C5091,C5098	C-CERAMIC,CHIP
2203-008876	C5103,C5117,C5149	C-CERAMIC,CHIP
2203-008876	C5151,C5160,C5184	C-CERAMIC,CHIP
2203-008876	C5185,C6038	C-CERAMIC,CHIP
2203-009167	C3005,C3022	C-CERAMIC,CHIP
2203-009328	C2000,C2032,C2051	C-CERAMIC,CHIP
2203-009328	C5139	C-CERAMIC,CHIP
2203-009618	C5126,C6000,C6005	C-CERAMIC,CHIP
2203-009733	C1077,C2016,C2019	C-CERAMIC,CHIP
2203-009733	C2099,C2100,C2101	C-CERAMIC,CHIP
2203-009733	C2102,C2103,C2104	C-CERAMIC,CHIP
2203-009733	C2105,C2107,C2109	C-CERAMIC,CHIP
2203-009733	C2110,C2112,C2113	C-CERAMIC,CHIP
2203-009733	C2114,C5000,C5020	C-CERAMIC,CHIP
2203-009733	C5021,C5039,C5040	C-CERAMIC,CHIP
2203-009733	C5106,C5109,C5112	C-CERAMIC,CHIP
2203-009733	C5115,C5122,C5135	C-CERAMIC,CHIP
2203-009733	C5136,C5161,C6003	C-CERAMIC,CHIP
2203-009733	C7007,C7010,C7015	C-CERAMIC,CHIP



## 5. MAIN Electrical Parts List

2203-009733	C7042,C7043,C7044	C-CERAMIC,CHIP
2203-009733	C7060,C7061,C7062	C-CERAMIC,CHIP
2203-009733	C7064	C-CERAMIC,CHIP
2203-010085	C5032,C5033,C5038	C-CERAMIC,CHIP
2203-010085	C5041,C5043,C5044	C-CERAMIC,CHIP
2203-010085	C5045,C5096,C5099	C-CERAMIC,CHIP
2203-010085	C5101,C5102,C5107	C-CERAMIC,CHIP
2203-010085	C5108,C5116,C5123	C-CERAMIC,CHIP
2203-010085	C5125,C5128,C5176	C-CERAMIC,CHIP
2203-010085	C5179,C5180,C5181	C-CERAMIC,CHIP
2703-002900	L1111	INDUCTOR
2703-002953	L1060,L1122,L3008	INDUCTOR
2703-002959	L1021,L1061,L1081	INDUCTOR
2703-002959	L1088,L1114,L2010	INDUCTOR
2703-003970	C1148	INDUCTOR
2703-004000	C1055,L1039,L2025	INDUCTOR
2703-004012	C1026,C1052,C1056	INDUCTOR
2703-004012	C1108,C2073,L1002	INDUCTOR
2703-004012	L1042,L1103,L1136	INDUCTOR
2703-004012	L2018,L2024	INDUCTOR
2703-004013	C1084,L1012,L1092	INDUCTOR
2703-004013	L1097,L2013,L2029	INDUCTOR
2703-004013	L2053,L2054	INDUCTOR
2703-004014	C1067,L1004,L1040	INDUCTOR
2703-004014	L1076,L1093,L1104	INDUCTOR
2703-004014	L1110,L1116,L1118	INDUCTOR
2703-004014	L1126,L1131,L2004	INDUCTOR
2703-004014	L3000	INDUCTOR
2703-004018	C1021,C1149,L1029	INDUCTOR
2703-004018	L1112,U1012	INDUCTOR
2703-004030	L1063,L1091	INDUCTOR
2703-004032	C1154,C3025,L1015	INDUCTOR
2703-004032	L1026,L1031,L1109	INDUCTOR
2703-004032	L1135	INDUCTOR
2703-004033	L2019	INDUCTOR
2703-004034	C1006,C1015,C1152	INDUCTOR
2703-004034	C2004,C2018,L1005	INDUCTOR
2703-004034	L1010,L1011,L1108	INDUCTOR
2703-004034	L1113,L2011,L2041	INDUCTOR

---

## 5. MAIN Electrical Parts List

---

2703-004035	C1029,C1107,C2029	INDUCTOR
2703-004035	L1000,L1001,L1055	INDUCTOR
2703-004035	L1083,L2030,L2031	INDUCTOR
2703-004037	C1017,C1070,C1161	INDUCTOR
2703-004037	L1023,L1043,L1105	INDUCTOR
2703-004037	L3016	INDUCTOR
2703-004038	C1059,C1061,C1071	INDUCTOR
2703-004038	C1137,C1140,C3015	INDUCTOR
2703-004038	L1017,L1020,L1069	INDUCTOR
2703-004038	L1089,L2000,L2020	INDUCTOR
2703-004295	L6002	INDUCTOR
2703-004317	L1030,L1033,L1095	INDUCTOR
2703-004317	L1098,L1099,L2002	INDUCTOR
2703-004317	L2015,L2016,L2017	INDUCTOR
2703-004317	L3012	INDUCTOR
2703-004328	C1076,L1009,L1062	INDUCTOR
2703-004328	L1090,L1121,U1029	INDUCTOR
2703-004362	L1056	INDUCTOR
2703-004366	L1137	INDUCTOR
2703-004367	C1090,C1133,L1053	INDUCTOR
2703-004703	L1107,L3018	INDUCTOR
2703-004763	L1019,L1065	INDUCTOR
2703-004764	C1136,C1153,L3013	INDUCTOR
2703-004853	L1003,L1045,L1125	INDUCTOR
2703-004901	L5006	INDUCTOR
2703-004947	L2058,L2059,L2060	INDUCTOR
2703-004947	L5003,L5004,L5005	INDUCTOR
2703-005085	L1037	INDUCTOR
2703-005086	C1135	INDUCTOR
2703-005089	C1091,L1051,L1052	INDUCTOR
2703-005089	L1120	INDUCTOR
2703-005116	L7004	INDUCTOR
2703-005118	L7002	INDUCTOR
2703-005295	L1013,L1047	INDUCTOR
2703-005296	C1100,L1048,L1050	INDUCTOR
2703-005445	L5014	INDUCTOR
2703-005505	L6000	INDUCTOR
2703-005546	L5015	INDUCTOR
2703-005555	L3004,L3007	INDUCTOR

---

## 5. MAIN Electrical Parts List

---

2703-005738	L5013	INDUCTOR
2703-005795	L5000,L5001,L5002	INDUCTOR
2703-005795	L5007,L5008,L5009	INDUCTOR
2703-005795	L5010,L5012	INDUCTOR
2703-005838	L5011	INDUCTOR
2703-005848	L2061,L2062,L2063	INDUCTOR
2801-005555	OSC5000	CRYSTAL
2901-001690	C4024,C4025,C4026	FILTER
2901-001690	C4027,C4028,C4029	FILTER
2901-001690	C4030,C4046,C4047	FILTER
2901-001690	C4057,C4068,C4069	FILTER
2901-001690	C4070,C4071,C4072	FILTER
2901-001690	C4073,C4075,C4076	FILTER
2904-002143	F1001,F2002	FILTER
2904-002280	F1016	FILTER
2904-002304	F1011	FILTER
2904-002339	F1015	FILTER
2904-002344	F1017	FILTER
2904-002405	F1003,U2004	FILTER
2904-002409	U3000	FILTER
2904-002417	F3000	FILTER
2904-002419	F1013	FILTER
2904-002428	F1002	FILTER
2909-001438	F1007,F1010,F2000	FILTER
2910-000296	U1031	FILTER
2910-000411	F1014	FILTER
2910-000417	F1004	FILTER
2911-000503	U1017	FILTER
2911-000504	U1028	FILTER
3003-001215	MIC6000	MIC
3301-001812	L6011,L6012	BEAD
3301-002235	C6013,L6005,L6007	BEAD
3301-002235	L6009	BEAD
3301-002237	L1027,L1049,L1068	BEAD
3301-002237	L3019,L6014	BEAD
3301-002238	L2014,L3006,L3010	BEAD
3301-002243	L6019,L6020,L7003	BEAD
3301-002243	L7005,L7006	BEAD
3301-002254	L7001	BEAD

## 5. MAIN Electrical Parts List

3301-002372	L5018,L5019,L6001	BEAD
3301-002372	L6013	BEAD
3705-001708	RFS1000,RFS1003	CONNECTOR
3705-001708	RFS2000	CONNECTOR
3705-001937	RFS1001,RFS1002	CONNECTOR
3709-001891	CD6000	CONNECTOR
3710-003871	SOC7001	CONNECTOR
3710-003874	SOC7000,SOC7004	CONNECTOR
3710-004008	SOC5000	CONNECTOR
3710-004027	SOC7002,SOC7003	CONNECTOR
3710-004109	SOC3000	CONNECTOR
3710-004501	SOC6000	CONNECTOR
3712-001626	ANT5005,ANT5006	CONNECTOR
3712-001634	ANT1001,ANT1002	CONNECTOR
3712-001634	ANT1003,ANT1004	CONNECTOR
3712-001634	ANT1005,ANT1007	CONNECTOR
3712-001634	ANT1008,ANT2000	CONNECTOR
3712-001634	ANT2002,ANT2004	CONNECTOR
3712-001634	ANT2005,ANT3002	CONNECTOR
3712-001634	ANT3003,ANT3004	CONNECTOR
3712-001634	ANT3005	CONNECTOR
3712-001666	ANT5002,ANT5003	CONNECTOR
3712-001666	ANT5004,ANT6000	CONNECTOR
3712-001666	ANT6001	CONNECTOR
4709-002416	F1006	RF IC
4709-002484	U1001	RF IC
4709-002761	U1000	RF IC
4709-002797	F1008,F1012,F1018	RF IC
4709-002818	F1000	RF IC
GH02-22306A	SC6002SP	TAPE
GH62-00070A	GAS6000,GAS6001	GASKET
GH63-16835A	SC6001	SCHIELD CAN
GH63-18031A	SC6000	SCHIELD CAN
GH63-19442A	SC6002	SCHIELD CAN
GH63-19443A	SC6003	SCHIELD CAN
GH98-46331A	SC6004	SCHIELD CAN
rf-2D-BARCODE	CON6000,CON6001	SCHIELD CAN

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.