
5. MAIN Electrical Parts List

Parts Code	Design LOC	Description
0404-001250	D6003	DIODE-SCHOTTKY
0404-001863	ZD6006	DIODE-SCHOTTKY
0406-001808	D6001	DIODE-TVS
0406-001860	ZD6000	DIODE-TVS
0406-001873	ZD9000,ZD9001	DIODE-TVS
0601-003899	LED6000	LED
0902-003402	U4000	IC
0903-002270	U8006	IC
1001-002055	F2002	IC
1001-002062	U2008,U3000	IC
1001-002064	U2006	IC
1001-002098	U1008	IC
1001-002110	U1001,U2007	IC
1001-002128	U2003	IC
1003-003229	U6006	IC
1201-004239	U7000,U7001	IC
1201-004308	U1013	IC
1201-004309	U1000,U1016	IC
1201-004313	U1002	IC
1201-004319	U1004,U1005,U1007	IC
1201-004342	U3006	IC
1203-008251	U6007,U9001	IC
1203-008395	U8002,U8004	IC
1203-008864	U8008	IC
1203-008955	U8003	IC
1203-009220	U8005	IC
1203-009234	U6004	IC
1203-009245	U9000	IC
1203-009320	U6003	IC
1203-009442	U8007	IC
1203-009470	U6000	IC
1203-009480	U5000	IC
1203-009515	U2016,U2017,U2025	IC
1203-009555	U3003	IC
1203-009593	U6005	IC
1203-009596	U6002	IC
1205-006278	U3007	IC
1205-006283	U7002	IC

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

1205-006344	U2012	IC
1205-006519	U3004	IC
1209-002513	U7005	IC
1209-002578	U7004	IC
1209-002711	U7003	IC
1404-001724	TH1000,TH3000,TH4000	THERMISTOR
1404-001724	TH6000	THERMISTOR
2007-000141	R4012,R4014	R-CHIP
2007-003015	R9002,R9008	R-CHIP
2007-007132	R5005	R-CHIP
2007-007134	R5004	R-CHIP
2007-007311	R6010	R-CHIP
2007-008052	R9001	R-CHIP
2007-008055	R6013,R7013,R9000	R-CHIP
2007-008056	R2008,R2009	R-CHIP
2007-008263	R4031	R-CHIP
2007-008419	R4028,R4054,R6016	R-CHIP
2007-008419	R6017,R6019,R7017	R-CHIP
2007-008419	R8006,R8007,R8009	R-CHIP
2007-008419	R8010	R-CHIP
2007-008486	R6002,R6004,R6005	R-CHIP
2007-008486	R6008,R6021,R6023	R-CHIP
2007-008516	R5003,R6015,R6018	R-CHIP
2007-008531	R6007	R-CHIP
2007-008587	R7002	R-CHIP
2007-008588	R3001,R3002	R-CHIP
2007-008647	L1005,L1013	R-CHIP
2007-008785	R2007,R6022,R6028	R-CHIP
2007-008800	R7012,R7014	R-CHIP
2007-008806	R3007	R-CHIP
2007-009111	R4035,R7009	R-CHIP
2007-009157	R6012	R-CHIP
2007-009171	R6006	R-CHIP
2007-009352	R7019,R7020,R7021	R-CHIP
2007-009352	R7022	R-CHIP
2007-009361	R1000,R1001	R-CHIP
2007-009408	R3003,R7000	R-CHIP
2007-009801	R3005	R-CHIP
2007-009866	R6009	R-CHIP

5. MAIN Electrical Parts List

2007-009920	R4013,R5000,R5001	R-CHIP
2007-010202	R6014	R-CHIP
2007-011262	R3006	R-CHIP
2007-011378	R3000,R3004,R3008	R-CHIP
2007-011378	R3009	R-CHIP
2007-011548	R1002,R1003	R-CHIP
2007-011591	R4000,R4002,R4004	R-CHIP
2007-011591	R4005,R4008,R4009	R-CHIP
2007-011591	R4017,R4018,R4019	R-CHIP
2007-011591	R4020,R4021,R4022	R-CHIP
2007-011591	R4023,R4024,R4039	R-CHIP
2007-011591	R4052,R4053	R-CHIP
2007-011594	R4001,R4003,R4006	R-CHIP
2007-011594	R4007,R4010,R4011	R-CHIP
2007-011594	R4015,R4016	R-CHIP
2007-011615	R4032,R4033	R-CHIP
2007-012197	R6020	R-CHIP
2203-000233	C3050,C3053,C3056	C-CERAMIC,CHIP
2203-000995	C3054	C-CERAMIC,CHIP
2203-005344	C6017	C-CERAMIC,CHIP
2203-005682	C1037,C1089,C2122	C-CERAMIC,CHIP
2203-005682	C7008,L2036	C-CERAMIC,CHIP
2203-005725	C3012	C-CERAMIC,CHIP
2203-005727	C1029,C2000,C2064	C-CERAMIC,CHIP
2203-005727	C2066,C2070	C-CERAMIC,CHIP
2203-005729	C1014,C7007	C-CERAMIC,CHIP
2203-005732	C7006,C7009	C-CERAMIC,CHIP
2203-005736	C1004,C1005,C1030	C-CERAMIC,CHIP
2203-005736	C1032,C1069,C1075	C-CERAMIC,CHIP
2203-005736	C1090,C12390,C2086	C-CERAMIC,CHIP
2203-005736	C2100,C2105,C2119	C-CERAMIC,CHIP
2203-005736	C3052,C3058,C3060	C-CERAMIC,CHIP
2203-005736	C6111,C6122,C7020	C-CERAMIC,CHIP
2203-005736	C7021,L1067,L1080	C-CERAMIC,CHIP
2203-005736	L1081,L2008,L2027	C-CERAMIC,CHIP
2203-005736	L3021	C-CERAMIC,CHIP
2203-005777	C2069,C2115,C3007	C-CERAMIC,CHIP
2203-005777	L1034,L1040,L1053	C-CERAMIC,CHIP
2203-005779	C8004,C8012,C8016	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005779	C8020,C8058	C-CERAMIC,CHIP
2203-005789	C1015,C1024,C1025	C-CERAMIC,CHIP
2203-005789	C1053,L1057,L1058	C-CERAMIC,CHIP
2203-005789	L2023	C-CERAMIC,CHIP
2203-005806	C3015	C-CERAMIC,CHIP
2203-006048	C7047	C-CERAMIC,CHIP
2203-006120	C9020,C9021	C-CERAMIC,CHIP
2203-006123	C2072,C3101,C9026	C-CERAMIC,CHIP
2203-006123	C9027	C-CERAMIC,CHIP
2203-006305	C2096,C6067	C-CERAMIC,CHIP
2203-006379	C7054	C-CERAMIC,CHIP
2203-006400	C3045,C3049,C3057	C-CERAMIC,CHIP
2203-006400	C6116,C7039,C7040	C-CERAMIC,CHIP
2203-006410	C1088	C-CERAMIC,CHIP
2203-006423	C1001,C1002,C1046	C-CERAMIC,CHIP
2203-006423	C1048,C1061,C3062	C-CERAMIC,CHIP
2203-006423	C5055,C5056,C5147	C-CERAMIC,CHIP
2203-006423	C5148,C5149,C5150	C-CERAMIC,CHIP
2203-006423	C5153,C5166,C5176	C-CERAMIC,CHIP
2203-006423	C5190,C5195,C5196	C-CERAMIC,CHIP
2203-006423	C5197,C5198,C6005	C-CERAMIC,CHIP
2203-006423	C6125,C7001,C7003	C-CERAMIC,CHIP
2203-006423	C7011,C7022,C7023	C-CERAMIC,CHIP
2203-006423	C7027,C7034,C7046	C-CERAMIC,CHIP
2203-006423	C7052,C7053,C8043	C-CERAMIC,CHIP
2203-006556	C2128	C-CERAMIC,CHIP
2203-006620	C1019,C1091	C-CERAMIC,CHIP
2203-006665	C3063	C-CERAMIC,CHIP
2203-006707	C3002	C-CERAMIC,CHIP
2203-006839	C1003,C1049,C1050	C-CERAMIC,CHIP
2203-006839	C1084,C6117	C-CERAMIC,CHIP
2203-006896	C6110	C-CERAMIC,CHIP
2203-007170	L1060	C-CERAMIC,CHIP
2203-007210	C1009,C1020,C3013	C-CERAMIC,CHIP
2203-007210	C3014,C4002,C7010	C-CERAMIC,CHIP
2203-007210	U100423	C-CERAMIC,CHIP
2203-007317	C2024,C3005,C3041	C-CERAMIC,CHIP
2203-007317	C5085,C5088,C5100	C-CERAMIC,CHIP
2203-007317	C5101,C5116,C5118	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007317	C7002,C7019,C7051	C-CERAMIC,CHIP
2203-007391	C5008,C5013,C5031	C-CERAMIC,CHIP
2203-007391	C5043,C5050,C5061	C-CERAMIC,CHIP
2203-007391	C5161,C5200,C6102	C-CERAMIC,CHIP
2203-007391	C6103,C6104,C7017	C-CERAMIC,CHIP
2203-007391	C7018,C7025	C-CERAMIC,CHIP
2203-007393	C2002,C2012,C2016	C-CERAMIC,CHIP
2203-007393	C2031,C2033,C2034	C-CERAMIC,CHIP
2203-007393	C2038,C2041,C2051	C-CERAMIC,CHIP
2203-007393	C2068,C2089,C2094	C-CERAMIC,CHIP
2203-007393	C2098,C2114,C2117	C-CERAMIC,CHIP
2203-007393	C2120,C2124,C5111	C-CERAMIC,CHIP
2203-007393	C6030,C6033,C6037	C-CERAMIC,CHIP
2203-007393	C6042,C6047,C6048	C-CERAMIC,CHIP
2203-007393	C6049,C6106,C6124	C-CERAMIC,CHIP
2203-007393	C7028,C7048,C8001	C-CERAMIC,CHIP
2203-007393	C8003,C8018,C8026	C-CERAMIC,CHIP
2203-007393	C8039,C8040,C8042	C-CERAMIC,CHIP
2203-007393	C8045,C8048,C8062	C-CERAMIC,CHIP
2203-007425	C6009	C-CERAMIC,CHIP
2203-007456	C6066	C-CERAMIC,CHIP
2203-007621	C1022,C1023,C1035	C-CERAMIC,CHIP
2203-007621	C1036,C1045,C1062	C-CERAMIC,CHIP
2203-007621	C1065,C1068,C1073	C-CERAMIC,CHIP
2203-007621	C1074,C2001,C2003	C-CERAMIC,CHIP
2203-007621	C2004,C2005,C2006	C-CERAMIC,CHIP
2203-007621	C2007,C2008,C2009	C-CERAMIC,CHIP
2203-007621	C2010,C2011,C2017	C-CERAMIC,CHIP
2203-007621	C2018,C2019,C2020	C-CERAMIC,CHIP
2203-007621	C2021,C2022,C2023	C-CERAMIC,CHIP
2203-007621	C2025,C2026,C2027	C-CERAMIC,CHIP
2203-007621	C2028,C2029,C2030	C-CERAMIC,CHIP
2203-007621	C2032,C2035,C2036	C-CERAMIC,CHIP
2203-007621	C2037,C2039,C2042	C-CERAMIC,CHIP
2203-007621	C2043,C2044,C2045	C-CERAMIC,CHIP
2203-007621	C2046,C2047,C2048	C-CERAMIC,CHIP
2203-007621	C2049,C2050,C2054	C-CERAMIC,CHIP
2203-007621	C2055,C2056,C2057	C-CERAMIC,CHIP
2203-007621	C2058,C2059,C2063	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007621	C2101,C2103,C2107	C-CERAMIC,CHIP
2203-007621	C2109,C3004,C3018	C-CERAMIC,CHIP
2203-007621	C3021,C3024,C3029	C-CERAMIC,CHIP
2203-007621	C3032,C6077,C6098	C-CERAMIC,CHIP
2203-007621	C7044,C7045,C8027	C-CERAMIC,CHIP
2203-007621	C8049	C-CERAMIC,CHIP
2203-007781	C6013,C6079	C-CERAMIC,CHIP
2203-007796	C3020,C3022,C3036	C-CERAMIC,CHIP
2203-007796	C3037,C3046,C3047	C-CERAMIC,CHIP
2203-007796	C3048,C5005,C5010	C-CERAMIC,CHIP
2203-007796	C5011,C5012,C5018	C-CERAMIC,CHIP
2203-007796	C5019,C5021,C5023	C-CERAMIC,CHIP
2203-007796	C5026,C5030,C5032	C-CERAMIC,CHIP
2203-007796	C5033,C5034,C5036	C-CERAMIC,CHIP
2203-007796	C5038,C5039,C5040	C-CERAMIC,CHIP
2203-007796	C5041,C5042,C5044	C-CERAMIC,CHIP
2203-007796	C5045,C5048,C5049	C-CERAMIC,CHIP
2203-007796	C5054,C5058,C5060	C-CERAMIC,CHIP
2203-007796	C5063,C5064,C5065	C-CERAMIC,CHIP
2203-007796	C5067,C5071,C5075	C-CERAMIC,CHIP
2203-007796	C5076,C5082,C5083	C-CERAMIC,CHIP
2203-007796	C5095,C5102,C5106	C-CERAMIC,CHIP
2203-007796	C5107,C5108,C5109	C-CERAMIC,CHIP
2203-007796	C5113,C5114,C5115	C-CERAMIC,CHIP
2203-007796	C5117,C5129,C5133	C-CERAMIC,CHIP
2203-007796	C5134,C5135,C5136	C-CERAMIC,CHIP
2203-007796	C5137,C5140,C5141	C-CERAMIC,CHIP
2203-007796	C5142,C5144,C5146	C-CERAMIC,CHIP
2203-007796	C5159,C5162,C5164	C-CERAMIC,CHIP
2203-007796	C5165,C5175,C5177	C-CERAMIC,CHIP
2203-007796	C5178,C5179,C5180	C-CERAMIC,CHIP
2203-007796	C5181,C5182,C5184	C-CERAMIC,CHIP
2203-007796	C5185,C5186,C5189	C-CERAMIC,CHIP
2203-007796	C5199,C5202,C5205	C-CERAMIC,CHIP
2203-007796	C5206,C5207,C5210	C-CERAMIC,CHIP
2203-007796	C5216,C5224,C6029	C-CERAMIC,CHIP
2203-007796	C6034,C6050,C6052	C-CERAMIC,CHIP
2203-007796	C6068,C6069,C6070	C-CERAMIC,CHIP
2203-007796	C6071,C6072,C6073	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-007796	C6076,C6101,C6121	C-CERAMIC,CHIP
2203-007796	C7005,C7016,C7029	C-CERAMIC,CHIP
2203-007796	C7035,C7123,C8002	C-CERAMIC,CHIP
2203-007796	C8011,C8014,C8015	C-CERAMIC,CHIP
2203-007796	C8019,C8021,C8022	C-CERAMIC,CHIP
2203-007796	C8029,C8031,C8032	C-CERAMIC,CHIP
2203-007796	C8033,C8038,C8055	C-CERAMIC,CHIP
2203-007796	C9018	C-CERAMIC,CHIP
2203-008095	C1076	C-CERAMIC,CHIP
2203-008097	C7012,C7031	C-CERAMIC,CHIP
2203-008242	C2065,C2110,C2123	C-CERAMIC,CHIP
2203-008242	C3008,C3016,C3017	C-CERAMIC,CHIP
2203-008242	C3019,C5024,C5035	C-CERAMIC,CHIP
2203-008242	C5037,C5051,C5052	C-CERAMIC,CHIP
2203-008242	C5059,C5062,C5066	C-CERAMIC,CHIP
2203-008242	C5068,C5069,C5091	C-CERAMIC,CHIP
2203-008242	C5093,C5104,C5155	C-CERAMIC,CHIP
2203-008242	C5158,C5163,C5168	C-CERAMIC,CHIP
2203-008242	C5170,C5172,C5173	C-CERAMIC,CHIP
2203-008242	C5183,C5187,C5191	C-CERAMIC,CHIP
2203-008242	C5193,C5203,C5212	C-CERAMIC,CHIP
2203-008242	C5214,C5218,C5220	C-CERAMIC,CHIP
2203-008242	C5222,C6023,C6032	C-CERAMIC,CHIP
2203-008242	C6036,C6041,C6043	C-CERAMIC,CHIP
2203-008242	C6045,C6046,C6051	C-CERAMIC,CHIP
2203-008242	C6074,C6107,C6108	C-CERAMIC,CHIP
2203-008242	C6115,C6118,C6123	C-CERAMIC,CHIP
2203-008242	C8005,C8006,C8037	C-CERAMIC,CHIP
2203-008243	C3082,C6040	C-CERAMIC,CHIP
2203-008400	C3059,C3099,C5017	C-CERAMIC,CHIP
2203-008466	C8000,C8007,C8009	C-CERAMIC,CHIP
2203-008466	C9019,C9028	C-CERAMIC,CHIP
2203-008572	C12380,C6007,C6008	C-CERAMIC,CHIP
2203-008572	C6014,C7013,C7014	C-CERAMIC,CHIP
2203-008572	C7015,C7036,C7037	C-CERAMIC,CHIP
2203-008654	C6065	C-CERAMIC,CHIP
2203-008749	C6006	C-CERAMIC,CHIP
2203-008860	C12124,C3044,C5014	C-CERAMIC,CHIP
2203-008860	C6002,C6004,C6010	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-008860	C6011,C6012,C6018	C-CERAMIC,CHIP
2203-008860	C6019,C6021,C6059	C-CERAMIC,CHIP
2203-008860	C6060,C6078,C6080	C-CERAMIC,CHIP
2203-008860	C6081,C6082,C6083	C-CERAMIC,CHIP
2203-008860	C6085,C6086,C6087	C-CERAMIC,CHIP
2203-008860	C6088,C6089,C7024	C-CERAMIC,CHIP
2203-008860	C7026,C8028,C8030	C-CERAMIC,CHIP
2203-008860	C8050,C8051,C8054	C-CERAMIC,CHIP
2203-008860	C9012	C-CERAMIC,CHIP
2203-008876	C1000,C1018,C1047	C-CERAMIC,CHIP
2203-008876	C1051,C1060,C1086	C-CERAMIC,CHIP
2203-008876	C1087,C2013,C2106	C-CERAMIC,CHIP
2203-008876	C2121,C3009,C3023	C-CERAMIC,CHIP
2203-008876	C3025,C3026,C3027	C-CERAMIC,CHIP
2203-008876	C3028,C3030,C3031	C-CERAMIC,CHIP
2203-008876	C3033,C3034,C3065	C-CERAMIC,CHIP
2203-008876	C3067,C3069,C3071	C-CERAMIC,CHIP
2203-008876	C3085,C3088,C3091	C-CERAMIC,CHIP
2203-008876	C3098,C3100,C6084	C-CERAMIC,CHIP
2203-008876	C6119,C6120,C8008	C-CERAMIC,CHIP
2203-008876	C8044,C8046,C8047	C-CERAMIC,CHIP
2203-009167	C3051,C3055	C-CERAMIC,CHIP
2203-009328	C5001,C5003,C5004	C-CERAMIC,CHIP
2203-009328	C5006,C5007,C5009	C-CERAMIC,CHIP
2203-009328	C5015,C5053,C5057	C-CERAMIC,CHIP
2203-009328	C5090,C5138,C5143	C-CERAMIC,CHIP
2203-009618	C9002,C9016,C9017	C-CERAMIC,CHIP
2203-009733	C5000,C5002,C5016	C-CERAMIC,CHIP
2203-009733	C5020,C5022,C5025	C-CERAMIC,CHIP
2203-009733	C5027,C5028,C5029	C-CERAMIC,CHIP
2203-009733	C5046,C5047,C5081	C-CERAMIC,CHIP
2203-009733	C5084,C5086,C5087	C-CERAMIC,CHIP
2203-009733	C5208,C5209,C6000	C-CERAMIC,CHIP
2203-009733	C6001,C6003,C6015	C-CERAMIC,CHIP
2203-009733	C6016,C6024,C6025	C-CERAMIC,CHIP
2203-009733	C6026,C6027,C6028	C-CERAMIC,CHIP
2203-009733	C6053,C6054,C6055	C-CERAMIC,CHIP
2203-009733	C6056,C6057,C6058	C-CERAMIC,CHIP
2203-009733	C6061,C6062,C6063	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-009733	C6064,C6075,C6090	C-CERAMIC,CHIP
2203-009733	C6091,C6092,C6093	C-CERAMIC,CHIP
2203-009733	C6097,C6099,C6109	C-CERAMIC,CHIP
2203-009733	C7000,C8010,C8013	C-CERAMIC,CHIP
2203-009733	C8017,C8023,C8035	C-CERAMIC,CHIP
2203-009733	C8036,C8067,C8068	C-CERAMIC,CHIP
2203-009733	C9003,C9004,C9005	C-CERAMIC,CHIP
2203-009733	C9006,C9007,C9008	C-CERAMIC,CHIP
2203-009733	C9009,C9013,C9014	C-CERAMIC,CHIP
2203-009733	C9015,L7012	C-CERAMIC,CHIP
2203-009875	C1081,C1082,C1093	C-CERAMIC,CHIP
2203-009875	C3003,C3035,C3038	C-CERAMIC,CHIP
2203-009875	C3064,C3066,C3068	C-CERAMIC,CHIP
2203-009875	C3070,C3072,C3073	C-CERAMIC,CHIP
2203-009875	C3074,C3075,C3076	C-CERAMIC,CHIP
2203-009875	C3077,C3079,C3081	C-CERAMIC,CHIP
2203-009875	C3083,C3084,C3087	C-CERAMIC,CHIP
2203-009875	C3089,C3090,C9000	C-CERAMIC,CHIP
2703-002649	C1006,L1020,L1082	INDUCTOR-SMD
2703-002901	C1052	INDUCTOR-SMD
2703-002907	C2067,L1028	INDUCTOR-SMD
2703-002953	C1016	INDUCTOR-SMD
2703-002955	C1044,L1044	INDUCTOR-SMD
2703-002959	C2075,L1048,L1088	INDUCTOR-SMD
2703-002959	L2019,L2037,R8000	INDUCTOR-SMD
2703-002959	R8001,R8002,R8003	INDUCTOR-SMD
2703-002959	R8004	INDUCTOR-SMD
2703-002999	C1055	INDUCTOR-SMD
2703-004000	C1031	INDUCTOR-SMD
2703-004001	L1049	INDUCTOR-SMD
2703-004012	C1059,C9071,L1036	INDUCTOR-SMD
2703-004012	L1039,L1045,L2012	INDUCTOR-SMD
2703-004012	L2014,L2020,L2044	INDUCTOR-SMD
2703-004013	C1092,L1004,L1009	INDUCTOR-SMD
2703-004013	L1010,L1014,L1030	INDUCTOR-SMD
2703-004013	L1042,L2001,L2006	INDUCTOR-SMD
2703-004013	L2028,L2029	INDUCTOR-SMD
2703-004014	L1033,L1037,L1073	INDUCTOR-SMD
2703-004014	L2043,L2060,L2062	INDUCTOR-SMD

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2703-004014	L3019	INDUCTOR-SMD
2703-004030	L1027	INDUCTOR-SMD
2703-004032	L2046	INDUCTOR-SMD
2703-004033	C1063,L1061	INDUCTOR-SMD
2703-004034	C1066,C1083,L1001	INDUCTOR-SMD
2703-004034	L1015,L1022,L1023	INDUCTOR-SMD
2703-004034	L1029,L1031,L2004	INDUCTOR-SMD
2703-004035	L2018,L2024,L2025	INDUCTOR-SMD
2703-004035	L3004	INDUCTOR-SMD
2703-004036	L1026	INDUCTOR-SMD
2703-004038	C2040,C2081,L1050	INDUCTOR-SMD
2703-004038	L2015,L2047,L3006	INDUCTOR-SMD
2703-004286	C2104,L2005	INDUCTOR-SMD
2703-004287	C2088,C2092,C2102	INDUCTOR-SMD
2703-004288	L1018,L2026,L2042	INDUCTOR-SMD
2703-004317	C1064,C1067,C1070	INDUCTOR-SMD
2703-004317	C1077,L1002,L1006	INDUCTOR-SMD
2703-004317	L1007,L1008,L1017	INDUCTOR-SMD
2703-004317	L1038,L1043,L1046	INDUCTOR-SMD
2703-004317	L1047,L3001	INDUCTOR-SMD
2703-004328	L1032,L1083,L1087	INDUCTOR-SMD
2703-004408	L8005	INDUCTOR-SMD
2703-004703	L2063	INDUCTOR-SMD
2703-004763	L2061	INDUCTOR-SMD
2703-004764	L1016,L1019,L1035	INDUCTOR-SMD
2703-005058	L3016	INDUCTOR-SMD
2703-005201	L6001	INDUCTOR-SMD
2703-005233	L7008,L7009	INDUCTOR-SMD
2703-005419	L9002	INDUCTOR-SMD
2703-005505	L2002,L2041,L2053	INDUCTOR-SMD
2703-005505	L7002,L7010	INDUCTOR-SMD
2703-005555	L3012,L3013	INDUCTOR-SMD
2703-005614	L1089	INDUCTOR-SMD
2703-005689	L6004	INDUCTOR-SMD
2703-005705	L2011,L2039,L2048	INDUCTOR-SMD
2703-005772	L9001	INDUCTOR-SMD
2703-005806	L9004	INDUCTOR-SMD
2703-005833	L6018,L6020,L6021	INDUCTOR-SMD
2703-005834	L6022	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-005838	L6000,L6002,L6003	INDUCTOR-SMD
2703-005838	L6005,L6006,L6008	INDUCTOR-SMD
2703-005838	L6009,L6010,L6011	INDUCTOR-SMD
2703-005838	L6012,L6013,L6014	INDUCTOR-SMD
2703-005838	L6015,L6023	INDUCTOR-SMD
2801-005547	OSC6000	CRYSTAL-UNIT
2901-001635	F9000	FILTER-EMI SMD
2903-001576	F3000	FILTER-CERAMIC
2904-002143	F2000,F2003	FILTER-SAW
2904-002366	F1001,F1008	FILTER-SAW
2904-002403	F1003,F2005	FILTER-SAW
2904-002405	F2001,F2007	FILTER-SAW
2904-002417	F3003	FILTER-SAW
2904-002432	F1004	FILTER-SAW
2910-000417	U1021	FILTER
2911-000487	U1003	FILTER
2911-000498	U1009	FILTER
3003-001256	MIC7000	MIC-CONDENSOR
3301-001534	L7006,L7007	CORE-FERRITE BEAD
3301-002122	L7014,L7015	CORE-FERRITE BEAD
3301-002223	L8001	CORE-FERRITE BEAD
3301-002235	L7003	CORE-FERRITE BEAD
3301-002236	L7005	CORE-FERRITE BEAD
3301-002237	L7004	CORE-FERRITE BEAD
3301-002238	L3014,L3015	CORE-FERRITE BEAD
3301-002239	L1011	CORE-FERRITE BEAD
3301-002243	L9000	CORE-FERRITE BEAD
3301-002312	L9003,L9005	CORE-FERRITE BEAD
3301-002331	L6007	CORE-FERRITE BEAD
3301-002356	L7011,L7013	CORE-FERRITE BEAD
3705-001708	RFS1000,RFS3000	CONNECTOR-COAXIAL
3705-001937	RFC1000,RFC1001	CONNECTOR-COAXIAL
3709-001892	CN7000	CONNECTOR-CARD EDGE
3710-002856	SOC8002	CONNECTOR-SOCKET
3710-003874	SOC8001,SOC8004	CONNECTOR-SOCKET
3710-004008	SOC6000	CONNECTOR-SOCKET
3710-004027	SOC8000,SOC8003	CONNECTOR-SOCKET
3710-004501	SOC9000	CONNECTOR-SOCKET
3712-001604	ANT2002,ANT2003	CONNECTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

3712-001604	ANT2004,ANT2005	CONNECTOR
3712-001604	ANT3000,ANT3005	CONNECTOR
3712-001604	ANT3009,ANT3010	CONNECTOR
3712-001604	ANT3011	CONNECTOR
3712-001626	ANT3004,ANT6002	CONNECTOR
3712-001626	ANT6003,ANT6005	CONNECTOR
3712-001626	ANT6006	CONNECTOR
3712-001633	ANT6000,ANT6001	CONNECTOR
3712-001633	ANT7000,ANT7001	CONNECTOR
3712-001694	ANT2001,ANT3001	CONNECTOR
3712-001731	ANT1000,ANT1001	CONNECTOR
3712-001731	ANT1002,ANT1003	CONNECTOR
3712-001731	ANT1004	CONNECTOR
3712-001969	SUS4000	CONNECTOR
3712-001976	ANT8000	CONNECTOR
4709-002226	F1000	RF-MODULE
4709-002756	F3004	RF-MODULE
4709-002797	F1002,F2004,F2006	RF-MODULE
GH63-20137A	SC9003	SC-A52S-RF-SUB6
GH63-20138A	SC9004	SC-A52S-PMIC-SUB6
GH63-20139A	SC9002	SC-A52S-MEM
GH98-46346A	SC9001	SC-A52-AP
1108-000677	UME5000	MEMORY
GH02-23206A	SC9001SP	SC-A52S-AP-NANOTIM

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.